

004

3.2 User Programming (Manager Programming)

Extension Name Set

Description

Assigns names to the extension numbers programmed in program [003] "Extension Number Set".

Selection

- Jack number: **1 through 8** (-1 / -2)
(-1 = first part, -2 = second part)
- Name: **10 characters (max.)**



Default

All jacks – Not stored

Programming

1. Enter **004**.

Display: 004 EXT NAME SET

2. Press **NEXT**.

Display: Jack NO?→

3. Enter a **jack number**.

To enter jack number 1, you can also press **NEXT**.

To select the second part (-2), press **NEXT** after entering a jack number.

Display: #1-1:Not Stored

4. Enter a **name**.

For entering characters, see "Station Speed Dialing Number/Name Assignment" in Section 2.2 "Station Programming".

To delete the current entry, press **CLEAR**.

To change the current entry, press **CLEAR** and enter the new name.

5. Press **STORE**.

6. To program another jack, press **NEXT** or **PREV**, or **SELECT** and the desired **jack number**.

7. Repeat steps 4 through 6.

8. Press **END**.