

## 3.2 User Programming (Manager Programming)

### System Speed Dialing Name Set

---

002

#### Description

Assigns names to the system speed dial numbers assigned in program [001] "System Speed Dialing Number Set". The KX-T7235 shows the stored name during System Speed Dialing.

#### Selection

- Speed dial number: **00 through 99**
- Name: **10 characters (max.)**



#### Default

All speed dial numbers – Not stored

#### Programming

1. Enter **002**.

Display: 002 SYS SPD NAME

2. Press **NEXT**.

Display: SPD Code?→

3. Enter a **speed dial number**.

To enter speed dial number 00, you can also press **NEXT**.

Display example: 00:Not Stored

4. Enter a **name**.

For entering characters, see "Station Speed Dialing Number/Name Assignment" in Section 2.2 "Station Programming".

To delete the current entry, press **CLEAR**.

To change the current entry, press **CLEAR** and enter the new name.

5. Press **STORE**.

6. To program another speed dial number, press **NEXT** or **PREV**, or **SELECT** and the desired **speed dial number**.

7. Repeat steps 4 through 6.

8. Press **END**.

#### Conditions

- Speed dial numbers are programmed in program [001] "System Speed Dialing Number Set".
- Each name has a maximum of 10 characters.

#### Feature References

System Speed Dialing (4.2/DPT Features, 4.4/Special Display Features, 5.2/Standard Telephone Features)